

---

# HYBRID INVERTER 12K EU USER MANUAL



Version: EN-UM-1.0-01    SN: 092.0007701



---

---

# CONTENTS

---

---

■	<b>About This Manual</b>	01
1	<b>Safety</b>	01
1.1	Safety Instruction	01
2	<b>Brief Introduction</b>	03
2.1	System Solution	03
3	<b>Installation</b>	04
3.1	Packaging List	04
3.2	Location Selection and Installation	04
3.2.1	Requirements for installation location	04
3.2.2	Installing the inverter	05
3.3	Connection Overview	07
3.3.1	System connection	07
3.4	PV Connection	08
3.5	Battery Connection	10
3.5.1	Battery power cable connection	10
3.5.2	Battery communication cable connection	10
3.6	Grid&EPS load Connection	12
3.6.1	Grid type selection	12
3.6.2	Grid and EPS load connection for split-phase service	12
3.6.3	AC cable connection	13
3.6.4	CT/Meter connection	13
3.7	Working with Generator	15
3.7.1	Generator system connection	15
3.7.2	Generator Startup and stop settings	17
3.8	AC Coupling Installation Connection	17
3.9	Parallel System Connection	19
3.9.1	Connection for paralleling system	19

3.10	Monitor System Setup	21
3.10.1	Wifi/GPRS/4G/WLAN dongle connection	21
3.10.2	Setup the Monitor system	22
3.10.3	Set homewifi password to dongle	22
3.10.4	Third party RS485 communication	23
4	<b>Operation Guide</b>	24
4.1	Operation Mode	24
4.1.1	Self-usage mode (Default)	24
4.1.2	Charge first mode	25
4.1.3	AC charge mode	26
4.2	LCD Display	26
4.2.1	Viewing information and alarm/fault record	26
4.2.2	Setting parameters	28
4.3	Start-up and shut down the inverter	30
4.3.1	Start up the inverter	30
4.3.2	Shut down the inverter	30
5	<b>Troubleshooting &amp; Maintenance</b>	31
5.1	Regular Maintenance	31
5.2	LED Displays	31
5.3	Troubleshooting Based On LCD Displays	31
5.4	Fan replacement	34

# 1. Safety

## 1.1 Safety Instruction

### General Safety Instructions

Inetrnationgl safety regulatio have been tirictly observed in the design and testing of the inverter Prior to any work ,carefully read all safety instructing and observe them at all times when working on or with the inveter.The installation must adhere to all applicable national or international standards or regulations.

Incorrect operation or work may cause:

- injury or death to the operator or a third party
- damage to the inverter and other properties belonging to the operator or a third party.

### Important Safety Notifications

There are various safety issues that must be carefully conveyd prior to during and after the installation, as well as During future operation and maintenance.The following are important safety notifications for the operator,owner, And user of this product under normal conditions of use..

### WARNING Avoid Misoperation and Inappropriate Usage

- All the work of this product (system design, installation, operation, setting , configuration and maintenance) must be carried out by qualified personnel as required.
- All connections must be in accordance with local and national regulations and standards.
- The inverter and system can inter-connected with the utility grid only if the utility grid permits it.
- All the warning labels or nameplates on the inverter must be clearly visible and must not be removed, covered or pasted.
- The installation should consider the safety of future users when choosing the right position and location as specified in this manual.
- Please keep the children away from touching or misusing the inverter and relevant systems.
- Beware of burning hurt, the inverter and some parts of the system could be hot when working, please do not touch the inverter surface or most of the parts when they are working. During inverter working states, only the LCD and buttons could be touched.

### NOTICE

- Please carefully read this manual before any work is carried out on this inverter, After the installation, please keep this manual carefully stored and easy to access at any time.
- The qualified personnel should have received training in electrical system installation and commissioning as well as dealing with hazards, They should also be accustomed with the manual and other related documents. As the installer or operator, they must be familiar with local regulations and directives.

### DANGER Dangers of High Voltages and Large Current


- Beware of high PV voltage. Please turn-off the DC switch of PV Panel output before and during the installation to avoid electric shock.
- Beware at the high grid voltage. Please turn-off the AC switch at the grid connection before and during the installation to avoid electric shock.
- Beware of large current of the battery output. Please turn-off the battery module before and during the installation to avoid electric shock.
- Do not open the inverter when it's working to avoid electric shock and damages from live voltage and current from the system.
- Do not operate the inverter when it's working, only the LCD and buttons can be touched in limited cases by qualified personnel, Other parts of the inverter can be touched when the inverter is in a safe state (e.g, fully shut-down).
- Do not connect or disconnect any connections (PV, battery, grid, communication etc.) of the inverter when it's working.
- Make sure the inverter is well grounded,An operator should make sure he is well protected by reasonable and professional insulation measurements (e.g,personal protective equipment (PPE).
- Inspect relevant existing wiring on-site of the installation is in good condition before installation, operation or maintenance.
- Inspect that connections are good between the inverter and PV, battery and grid during installation to prevent damages or injuries caused by bad connections.

## 2. Brief Introduction


### 2.1 System Solution

This product and its associated system are suitable for the following system applications (system diagram):


**A. Solar and battery storage system**




**B. AC Coupling with existing solar**




**C. On-grid solar system without battery (Support EPS even without battery)**




**D. Off-grid and back-up applications**



**E. Single and three phase paralleling system**



**F. Energy storage system with peak shaving Function**



## 3. Installation

### 3.1 Packaging List & Storing

#### Packaging List


When the packaging is unpacked, the inner components should match those listed in the list below.




### 3.2 Location Selection and Installation

#### 3.2.1 Requirements for installation location


- The mounting wall should be strong enough to bear the weight of the inverter.
- Please maintain the minimum clearances presented below for adequate heat dissipation.



c. Never position the inverter in direct sunlight, rain, or snow. Please refer to the figure below and choose a well-shaded site or a shed to protect the inverter from direct sunlight, rain, and snow etc. PROTECT the LCD screen from excessive UV exposure




d. The inverter should be installed upright on a vertical surface.




### 3.2.2 Installing the inverter

The inverter is wall-mounted type and, should be installed on a vertical, solid mounting surface, such as wood studs, brick or concrete wall. Two or more persons may be needed to install the inverter due to its weight. The slots on the mounting bracket can accommodate various stud spacings from 12 inches (305mm) to 16 inches (406mm).




The mounting steps are as below: (Use brick wall as example)


**Step1.** Mark the drill hole positions with the mounting bracket, then drill four 48(5/16inch) diameter holes, making sure the depth of the holes is deeper than 50mm(2inches).



**Step2.** Install and tighten the expansion bolts into the holes. Then use the corresponding nuts and washers (packaged together with the expansion bolts) to install and fix the wall-mounting bracket on the wall.



**Step3.** Hang the inverter onto the wall-mounting bracket and lock the inverter on the wall using 2 self-tapping screws on the top of the inverter.



#### For installation on wood studs


Fasten the mounting bracket on the studs with 4 wood screws, then hang the inverter onto the bracket and lock the inverter on the wall with 2 self-tapping screws.

Please note that the wood screws and self-tapping screws are not provided with the inverter. Installers need to prepare the screws before installation.

### 3.3 Connection Overview

#### 3.3.1 System Connection


The system connection diagram is as below.





Please prepare the breakers before connecting, breakers selection recommendation for both DC and AC

Inverter model	12K
PV Breakers(2Px4)	MPPT1 string 1 : 600V/20A MPPT1 string 2 : 600V/20A MPPT2: 600V/20A MPPT3: 600V/20A
Battery Breaker(2P)	100V/300A
Main Breaker(2P)	200A/240Vac when ups is used for whole home backup 100A/240Vac when ups is used for partial load backup
Load Breaker(2P)	200A/240Vac when ups is used for whole home backup 100A/240Vac when ups is used for partial load backup
Geneartor breaker	100A

#### Overview of Connection Ports



### Overview of the cable box



- a). DRM port(Applied only in AU)
- b). Battery communication port(CAN&RS485)  
please check Chapter 3.5.2 for Pin definition
- c). CT Interface: please check Chapter 3.6.4 for CT connection
- d). INV 485: Debugging port
- e). Parallel communication port  
please check Chapter 3.9 for Parallel connection
- f). FAN1/2/3
- g). TEMP: Connection for temperature sensor of lead-acid battery
- h). Meter 485B&485A: For Meter communication
- i). VIN/+12V: Connect a outside emergency switch on these 2 terminals
- j). CAN Matching resistance: Set DIP switch when use inverters in parallel
- k). GEN(NO, NC): Connection for generator auto-start function
- l). DRY(NO,NC): reserved

### 3.4 PV Connection

The PV connection of this hybrid inverter is the same as that of a traditional on-grid solar inverter (string inverter).

#### WARNING


\* Please double check the lowest ambient temperature of the installation location. The rated Voc on solar panel nameplate is obtained at 25°C. As the ambient temperature drops, the Solar panel Voc increases. Please ensure the Maximum solar string voltage corrected at the lowest temperature does not exceed the inverter's maximum input voltage of 550V.

#### Cable Requirement:

Cable Size	Minimum Voltage
10-8 AWG(5-8 mm <sup>2</sup> )	600V

**NOTICE**

1. The inverters have triple MPPTs. For MPPT1, users can connect two strings. For MPPT2 and MPPT3, users can connect one string.
2. When users connect 2 strings to MPPT1, make sure the two strings have the same quantity of solar panels. The inverter will limit the total MPPT1/MPPT2/MPPT3 input current to 25A/15A/15A automatically.
3. The inverter will limit the max solar input power to 18kW total.




### 3.5 Battery Connection

#### 3.5.1 Battery power cable connection

Cable Requirement:

Model	Cable Size	Minimum Voltage	Torque for cable connection	OT ring
12K	3/0-4/0 AWG(85-100 mm <sup>2</sup> )	600V	20(N.M)	RNB100-10


- Step 1: Strip 1/4-5/16inch(6-8mm) insulation from the cable end and crimp OT rings for the cable ends.
- Step 2: Route the battery power cable through the cable gland, connect positive to BAT+, negative to BAT-.
- Step 3: Secure the conduit fitting to the enclosure using the counter nut.
- Step 4: Fasten the OT rings of battery positive and negative cables to the lugs according to the markings.
- Step 5: Fix the cable gland in place.





#### 3.5.2 Battery communication cable connection

Correct battery communication cable must be used to connect the battery to the inverter when users choose lithium-ion battery type. Please select 'Lead-acid' type if the lithium battery can not communicate with the inverter. The battery communication port on inverter is an Rj45 socket, Pin for the RJ45 plug of the communication cable is as below. Make the communication cable according to the below inverter Pin and the correct pinout of communication port on battery. The inverter supports both CAN and RS485 communication.

Pin	Description
1	NC
2	GND
3	NC
4	BAT CAN H
5	BAT CAN L
6	NC
7	BAT RS485 A
8	BAT RS485 B



After battery power cable and communication cable connection, users need to enter Advanced setting and choose Battery type and brand on the inverter LCD



**NOTICE**

**For Li-ion battery**

1. Please make sure the lithium-ion battery to be used is compatible with Luxpower inverters. Please contact your distributor for an updated battery compatible list.
2. If you are using multiple battery modules with the inverter, the inverter communication cable must be connected to the master battery. Please check with your battery supplier for battery master and slave settings.


**For Lead-acid battery**

1. The temperature sensor for the lead-acid battery is optional. If you need it, please contact the distributor for purchasing.
2. There are three stages for lead-acid battery charging. For charging/discharge related parameters, please check the charge /discharge settings page.

**3.6 Grid&EPS load Connection**



**3.6.1 Grid type and regulation selection**

The inverter has passed the main grid-connection regulations NRS097:



**3.6.2 Grid and EPS load connection**

If the busbar rating in the main panel can meet the NEC705.12(B)(3) requirements, Otherwise, a Line side-connection can be made to avoid an expensive main panel upgrade.






### 3.6.3 AC cable connection

Cable Requirement:

Current	Cross-section	Cable Diameter	Minimum Voltage	Torque for cable connection	OT ring
100A	3-2AWG(25-35mm <sup>2</sup> )	6-7mm	600V	41(N.M)	RNB38-10S
200A	2/0-3/0AWG(70-85mm <sup>2</sup> )	9-10mm	600V	41(N.M)	RNB100-10

- Strip off 5/16-3/8inch(8~10mm) insulation sleeve on the cables.
- Use wire ferrules if the cables are made of fin stranded wires.
- Secure the conduit fitting to the enclosure using the counter nut of the fitting.
- Fasten the grid and EPS load cables to the terminal block in accordance with the markings.
- Secure conduit to the conduit fitting.
- Check that the cables are connected correctly and securely, then take appropriate measures to ensure that the conduit and conduit fitting are secured reliably, and seal the cable entry holes.







### 3.6.4 CT/Meter Connection

To measure the power imported from and exported to the grid, a pair of CT or one triphase meter must be installed at the service entry point in or near the main service panel. We standardly supply 1 CT for one inverter.

#### CT Port Pin definition

The CT interface for 1 CT connection is a RJ45 port, We have made a RJ45 plug on those 1 CT in advance, so you can connect it to the port directly.

Pin	Description
1-4	reserve
5	reserve
6	reserve
7	CT1N
8	CT1P




Please refer to the above connection diagram for the correct positions of CTs. The arrows on the CTs must point to inverter side.

#### CT Clamp Ratio

The Luxpower inverters support two ratios of CT clamp- 1000:1 and 3000:1 . The CT ratio of the CTs in the accessory bag is 1000:1. If you are using a 3rd party CT, please ensure the CT ratio is either 1000:1 or 3000:1, and then select the correct CT ratio setting in the inverter monitor page or on the inverter LCD.

#### Extend CT clamp cable

The CT wires can be extended with a common ethernet cable if the length is not enough. An RJ45 adapter is needed for the extension. The CT wires can be extended up to 300ft(around 100m).



RJ45

FAN1  
FAN2  
FAN3  
TEMP  
Meter 485B  
485A  
GND  
RSD  
+VIN  
+12V  
NO  
NC  
L  
N  
DRY  
NC

**Basic** PV input  Meter or CT   
 MODBUS addr  Meter type   
**Charge** Vpv start (V)  CT ratio



**Discharge** Offgrid output  EPS output without Battery  Micro-grid    
**Advanced** Seamless switch  Charge last  RSD disable   
**Debug** AC couple  CT direction reversed   
**Device info.** Smart load   
 PV Arc  PV Arc fault clear

**Meter Connection**  
 Currently only EASTRON SDM630-Modbus meters can be used. If you need to use a meter for import/export detection instead of CTs, you need to connect it to the Meter 485A and 485B terminals on the inverter, please contact Luxpowertek for detailed instructions.

### 3.7 Working with Generator

#### 3.7.1 Generator system connection


This hybrid inverter can work with generator. There are Gen ports on the inverter for generator connection.




When the generator is started, all the loads connected to EPS will be supplied by the generator. Meanwhile the battery will be charged.

The pass-through relay on the generator port is 90A. When the generator is on, please ensure the total load and charge current will not exceed 90A.

The generator start signal shall be connected to the COM board GEN(NO,NC port) if users want to start the generator remotely.



### 3.7.2 Generator Startup and Stop settings



It depends on the Bat charge control setting, The system will use either battery SOC or battery voltage to judge determining whether system needs to start or stop the generator.

#### Generator Start Conditions


- When utility fails and
- When battery is discharged to cut-off settings or there is force charge request from battery.
- or when the battery voltage or SOC is lower than the Generator Charge start Volt/SOC settings,

#### Generator Stop Conditions

when battery voltage or SOC is higher than Charge end Volt/SOC settings value.

## 3.8 AC Coupling Installation Connection


The inverter supports AC coupling connection with the existing grid-interactive solar system. The existing solar system is connected to the inverter's EPS port.



When the grid is on, the EPS terminal is connected to the grid terminal inside the inverter by a passthrough relay. In this case the hybrid inverter will bypass the interactive inverter AC to grid in this situation. The spec of the passthrough relay is 200A.

When the grid is off, the hybrid inverter will work as a power source for the grid interactive inverter to synchronize and feed power to the micro-grid. The loads will be first supplied by solar power. If solar panels are generating more power than load consumption, the excess solar power will be stored in the battery. When solar power exceeds the sum of load power and max battery charging power, e.g. when the battery is nearly full. The inverter will signal the grid interactive inverter to reduce power via the frequency shifting power reduction mechanism, thus to maintain the balance of generation and consumption of the microgrid system.

Users need to enable the AC coupling function when they connect their existing on grid system to the EPS terminal.



## 3.9 Parallel System Connection


### 3.9.1 Connection for paralleling system

The hybrid inverter supports parallel connection to expand power and energy capacity to suit different using scenarios.

Up to 10 units can be paralleled to reach a capacity of 120kW. Wiring diagram is as below,


The manual bypass switch connects loads to EPS panel for default. When inverters fail, users can switch the loads to utility.

#### Single Phase parallel system




Please put the 2-bit CAN balancing resistor switch to ON status for the first and end inverter of the daisy chain loop.

#### Three Phase parallel system




Please put the CAN communication PIN to on status for the first and the end inverter




If the parallel cable is not enough or long enough, please make a straight pin to pin cable

### Settings for paralleling function in monitor system

1. Set up monitoring for the system, add all dongles to one station. Users can login to visit the monitoring system, Configuration->Station->Plant Management->Add a dongle to add dongles.



2. If the system shares a single battery bank, enable the shared battery function otherwise disable the shared function.
3. Set the system as a parallel group in the monitor system




Please contact your inverter supplier for more detailed guidance for paralleling system

## 3.10 Monitor System Setup

### 3.10.1 Wifi/GPRS/4G/WLAN dongle connection


Users can use a WiFi/ WLAN /4G /2G dongle to monitor their inverter, and view the monitoring data on a computer or smart phone remotely.

To view data on a smartphone, please download the LuxPowerView APP from the Google Play or Apple APP store, then login with their user account.




### 3.10.2 Setup the monitor system

1. Sign up an account on the mobile phone APP or Website  
The "customer code" is a code we assigned to your distributor or installer. You can contact your supplier for their code.




2. Create station and add dongle for the station



### 3.10.3 Set homewifi password to dongle

1. Connect your mobile phone to the "BAxxxxxxx" wireless network where "BAxxxxxxx" is the serial number of the WiFi dongle.
2. Click the "WiFi MODULE CONNECT" button on the APP
3. Select the home WiFi that the WiFi dongle is to be connected to and enter the WiFi's password. And then click "HomeWifi Connect". The WiFi dongle will restart and try to connect to our server automatically.
4. Check the LEDs' status on the WiFi dongle. The middle light should be solidly lit when the WiFi dongle connects to our server successfully.



5. Now you can disconnect your mobile phone from the "BAxxxxxxx" wireless network. Login on the APP with your account, you'll find the inverter information already appears. Now you'll be able to monitor and control the inverter remotely on any smart phone or computer that has an Internet connection.

Please download the following guides for setting up WiFi dongle and monitoring account at

Document Reference:

1. Wifi Quick Guidance

Quick guidance for setting connection of WiFi module to home WiFi, you can also find a printed version in the packaging of the WiFi module.

2. Monitor system setup for Distributors and Monitor system setup for endusers

Account registration, the description of each items and parameters, setting parameters

3. Lux\_Monitor\_UI\_Introduction


Introduction of monitor interface

### 3.10.4 Third party RS485 communication


Meter 485B&485A: are used when the Meter is not connected. These two pins can be used to communicate with the inverter using our Rs485 modbus protocol.

INV485: This interface is shared with the WIFI module. If the WIFI module is not in use, users can use this interface to communicate with the inverter.

Please contact your distributor to get the protocol for third party APP development.



Pin	Description
1	485B
2	485A
3-8	/



## 4. Operation Guide

### 4.1 Operation Mode and Function

The inverter has different working modes to meet customers' various demands, The working modes are as below:

#### 4.1.1 Self-usage Mode (Default)

In this mode, the priority order of load supply sources is Solar>Battery>Grid. The priority order of solar power usage is Load>Battery>Grid.



➤ **Application Scenarios**

Self consumption mode will increase the self consumption rate of solar power and reduce the energy bill significantly

➤ **Related Settings**

Effective when Charge Priority , AC Charge, and Forced discharge are disabled

➤ **Example**




## 4.1.2 Charge First Mode

The priority order of solar power usage will be Battery >Load >Grid. During the Charge Priority time period, load is first supplied with grid power. If there is excess solar power after battery charging, the excess solar power will take a load together with grid power.


### ► Application Scenarios

When users want to use solar power to charge batteries, grid power is used to supply loads.

### ► Related Settings



### ► Example




## 4.1.3 AC Charge Function

Users can charge batteries with grid power when electricity prices are cheap, and discharge battery power to supply load or export to the grid when electricity prices are high.


### ► Application Scenarios

When users have a Time of Use(TOU) rate plan.

### ► Related Settings




## 4.1.4 Grid peak-shaving Function



### • Grid peak-shaving & Grid peak-shaving power(kW):

Is used to set the maximum power that the inverter will draw from its grid power.

## 4.1.5 Smart load Function



• **Smart Load:** This function is to make the Gen input connection point as a load connection point, if you enable it, inverter will supply power to this load when the battery SOC and PV power is above a user setup value. e.g. Smart load start SOC=90%, Smart load end SOC=85%, Start PV power=300W, it means: When the PV power exceeds 300W, and the battery system SOC gets to 90%, the Smart Load Port will switch on automatically to supply the load which is connected on this side. When the battery reaches SOC<85% or PV power<300w, the Smart Load Port switch off automatically.

### Note:

If you enable the Smart load function, it's forbidden to connect the generator at the same time, otherwise the device will be damaged!

## 4.2 LCD Display

Users can view the inverter's running status, real time power, daily and accumulated energy information conveniently on the inverter's LCD. In addition to the above information, users can also check alarm and fault records on the display for troubleshooting.

### 4.2.1 Viewing information and alarm/fault record





#### > Home Page

Touch the screen to light it up if it's in sleep mode. The Home page will appear on the display. Users will see a system overview diagram along with the real time information of each component, such as battery SOC, battery charging/discharging power, grid import/export power, load power, etc. On the right part of the screen, users can check daily and accumulated solar energy, battery charged/discharged energy, grid imported/exported energy, as well as load consumption.




#### > Detailed System Information

Click on the pie icon at the bottom of the screen and you'll be able to view the detailed real time solar information, battery information, grid information and EPS output information.



#### > Fault/Alarm Information


Touching the bell icon at the bottom of the screen, you'll see all the current and historical fault & warning information on this page.



### 4.2.2 Setting Parameters

Clicking on the gear icon at the bottom of the screen, you'll get into the parameter setting page of the inverter.

#### a. Basic settings




- **Standby:** Is for users to set the inverter to normal status or to standby status. In Standby status, the inverter will stop any charging or discharging operation, as well as solar-feed-in.
- **Restart inverter:** Restart the system, please note the power maybe interrupted when restarted.

- **Feed-in Grid:** Is for users to set a zero export function. If exporting solar power is not allowed, users need to disable the "Feed-in Grid" option. If users' utility meter is tripped with even a little solar export, "Fast zero export" can be enabled thus The export detection and adjustment will take place every 20mS, which will effectively avoid any solar power being exported. If export is allowed, users can enable "Feed-in Grid" and set a maximum allowable export limit in "Feed-in Power"(kW).



## b. Charge setting



**Bat charge control:** Users can decide to use SOC or BatV to control charge and discharge logic depending on battery type.

**Bat charge current limit(A):** users can set Max charge current.

**AC Charge:** Utility charge configuration. If users want to use grid power to charge their batteries, they can enable "AC Charge", set time periods when AC charging can happen, AC Charge power(kW) to limit utility charging power, and "Stop AC Charge SOC(%)" as the target SOC for utility charging. "Stop AC Volt(V)" as the target battery voltage for utility charging.

**Charge first:** PV charge configuration. When using enable Charge first, PV will charge the battery as a priority, set time periods when PV charge can happen, charge first power(kW) to limit PV charge power, and "Charge first SOC(%)" as the target SOC for PV charge first. "Charge first Volt(V)" as the target battery voltage for PV Charge first.


**Lead acid:** When using Lead-acid battery, you need to set parameters in these programs, Follow the battery manufacturer's recommendation.

**Generator**

**Bat charge current limit(A):** Set the Max. battery charge current from the Generator. The Generator will start charging according to the Charge start Volt/SOC, and stop charging when the battery voltage or SOC reaches the Charge end Volt/SOC value.

**Gen rated power:** Maximum allowable power from generator.

## c. Discharge setting




**Bat discharge control:** You can choose "Use SOC %" or Use Bat V" to control the battery discharge state.

**Discharge current limit(A):** The Max. discharge current from battery.

**Discharge start power(W):** The Min. value can be set to 50. When the inverter detects the import power is higher than this value, battery start discharging, otherwise battery will keep standby.

**On-grid EOD(%) and Off-grid EOD(%) /On-grid Cut-off(V) and Off-grid Cut off(V):** End of discharge SOC/Cut off voltage in on-grid and off-grid condition respectively.

**Forced discharge:** Settings for battery force discharge within certain time period. In the preset time period, the inverter will discharge battery at the power set by "discharge power", until battery SOC or voltage reaches "Stop discharge "value.




**Grid peak-shaving & Grid peak-shaving power(kW):** Is used to set the maximum power that the inverter will draw from its grid power.

**Smart Load:** This function is to make the Gen input connection point a load connection point, If you enable it, the inverter will supply power to this load when the battery SOC and PV power is above a user setup value. e.g. Smart load start SOC=90%, Smart load end SOC=85%, Start PV power=300W, it means: When the PV power exceeds 300W, and the battery system SOC gets to 90%, the Smart Load Port will switch on automatically to supply the load which is connected on this side. When the battery SOC < 85% or PV power < 300W, the Smart Load Port will switch off automatically.

Note: If you enable the Smart load function, it's forbidden to connect the generator at the same time, otherwise the device will be damaged!

## d. Advanced settings

Advanced settings are mainly done by the installer after installation.



**Grid type:** You can choose by yourself, 230V

**Grid regulation:** Please choose SouthAfrica or General

**Battery type:** No battery, lead-acid or lithium-ion.

If lead-acid battery is selected, please input correct battery capacity

If lithium-ion battery is selected, please choose the battery brand in the Lithium brand drop down list.

**Offgrid output:** It is for users to set if the inverter provides backup power or not when the grid is lost. If users want the load to be seamlessly transferred to the inverter backup power, "Seamless switch" must be enabled. If customers don't have a battery installed yet, but still wish to have inverter backup power with only solar panels connected, "PV Grid Off" can be enabled to use solar power to supply load when the grid fails or load-shedding happens. Micro-grid: only needs to be set when the generator is connected to the inverter's grid port. With this option enabled, the inverter will use AC power to charge the battery and won't export any power through the grid port if AC power is present at the inverter's grid port.

**Charge last:** When users want to use solar power in the order of loads -- grid export -- battery charging.

**AC couple:** Enabled when you want to use the inverter as an AC coupled model.

**CT direction reversed:** When the CT is installed in the wrong direction the installer can modify it by selecting it. There is no need to reconnect. In the order of loads -- grid export -- battery charging.

The supported CT ratio is 1000:1 and 3000:1. The default CT ratio is 1000:1. If a 3rd party CT is to be used, please ensure its CT ratio is either 1000:1 or 3000:1, and set it accordingly. The battery brand in the Lithium brand drop down list.

**Meter type:** Please select it according to the meter that's to be installed.

## 4.3 Start-up and shut down the inverter

### 4.3.1 Start up the inverter

Step1. Turn on the battery system first turn on the DC breaker between the battery and inverter.

Step2. Make sure the PV voltage of the strings is higher than 120V ,and check if the inverter works in PV charge or PV charge back-up mode.

Step3. Make sure steps 1and 2 above work properly before turning on the grid power or generator breaker, and check if the inverter can go to bypass mode and on-grid mode normally.

### 4.3.2 Shut down the inverter

Danger: Do not disconnect the battery , PV and AC input power under load.

If there is an emergency issue , and you have to shut down the inverter ,please follow the steps as below.

Step1. Turn off the Grid breaker of the inverter.

Step2. Switch off the load breaker.

Step3. Turn off the PV breaker and then the battery breaker, waiting for the LCD to go off.

## 5. Troubleshooting & Maintenance

### 5.1 Regular Maintenance

#### • Inverter Maintenance

a. Check the inverter every 6 months or 1 year to verify if there are damages to cables, accessories, terminals and the inverter itself.





b. Check the inverter every 6 months to verify if the operating parameters ar normal and there is no abnormal heating or noise from the inverter.

c. Check the inverter every 6 months to confirm there is nothing that covers the inverter heat sink, if there is, shut-down the inverter and clear the heat sink.

#### • Battery Maintenance

Follow the manufacturer's requirements on maintenance. When you carry out these tasks on batteries, please make sure to fully shut-down the inverter for safety consideration.

### 5.2 LED Displays

LED	Display	Description	Suggestion
Green LED	Solid lit 	Working normally	
	Flashing 	Firmware upgrading	Wait till upgrading complete
Yellow LED	Solid lit 	Warning, inverter working	Need troubleshooting
Red LED	Solid lit 	Fault, inverter stop work	Need troubleshooting

### 5.3 Troubleshooting Based On LCD Displays

Once there is any warning or fault occurring, users can troubleshoot according to the LED status and the warning/fault information on the LCD.

#### 1. Fault on the LCD


If the dot on the left of the fault item is red, it means the fault is active. When it is grey, it means the fault is deactive

Fault status	Alarm status	Fault record	Alarm record
● M3 Rx failure	● M8 Tx failure	● Eps connect fault	● Neutral fault
● Model fault	● M3 Tx failure	● PV volt high	● PV short circuit
● Eps short circuit	● Bus short circuit	● Hard over curr	● Temperature fault
● Relay fault	● Vbus over range	● Inconsistent	● M8 Rx fault
● ReservedA	● ReservedB	● ReservedC	● ReservedD
● ReservedE	● ReservedF	● ReservedG	● ReservedH
● ReservedI	● ReservedJ	● ReservedK	● ReservedL

Fault	Meaning	Troubleshooting
M3 Rx failure	M3 microprocessor fails to receive data from DSP	Restart inverter, if the error still exists, contact Luxpower service or your inverter supplier.
Model fault	Incorrect model value	
Eps short circuit	Inverter detected short-circuit on EPS output terminals	1. Check if the L1, L2 and N wires are connected correctly at the inverter's EPS output port; 2. Disconnect the EPS breaker to see if the fault remains. If fault persists, contact Luxpower service or your inverter supplier.
Eps power reversed	Inverter detected power flowing into EPS port	Restart the inverter, If the error still exists, contact Luxpower service or your inverter supplier.
Bus short circuit	DC Bus is short circuited	
Relay fault	Relay abnormal	
M8 Tx failure	DSP fails to receive data from M8 microprocessor	
M3 Tx failure	DSP fails to receive data from M3 microprocessor	Please check if the PV string voltage is within the inverter specification. If string voltage is within range, and this fault still appears, contact Luxpower service or your inverter supplier.
Vbus over range	DC Bus voltage too high	
Eps connect fault	EPS port and grid port are connected mixed up	
PV volt high	PV voltage is too high	Please check if the PV string voltage is within the inverter specification. If string voltage is within range, and this fault still appears, contact Luxpower service o your inverter supplier.
Hard over curr	Hardware level over current protection triggered	Restart inverter, If the error still exists, contact Luxpower service or your inverter supplier.
Neutral fault	Voltage between N and PE is greater than 30V	Check if the neutral wire is connected correctly.
PV short circuit	Short circuit detected on PV input	Disconnect all PV strings from the inverter. If the error persists, contact Luxpower service or your inverter supplier.
Temperature fault	Heat sink temperature too high	Install the inverter in a place with good ventilation and away from direct sunlight. If the installation site is okay, please check if the NTC connector inside the inverter is loose.
Bus sample fault	Inverter detected DC bus voltage lower than PV input voltage	Restart inverter, If the error still exists, contact Luxpower service or your inverter supplier.
Inconsistent	Sampled grid voltage values of DSP and M8 microprocessor are inconsistent	
M8 Rx fault	M8 microprocessor fails to receive data from DSP	

## 2. Alarm on the LCD

If the dot on the left of fault item is yellow, it means the fault is active. When it is grey, it means the fault is deactive



Alarm	Meaning	Troubleshooting
Bat com failure	Inverter fails to communicate with battery	Check if the communication cable is correct, and if you have chosen the correct battery brand on the inverter LCD. If all is correct but this error persists, please contact Luxpower service or your inverter supplier.
Meter com failure	Inverter fails to communicate with the meter	1. Check if the communication cable is connected correctly and in good condition. 2. Restart inverter. If the fault persists, contact Luxpower service or your inverter supplier.
Bat Fault	Battery cannot charge or discharge	1. Check the battery communication cable for correct pinout on both inverter and battery end; 2. Check if you have chosen an incorrect battery brands; 3. Check if there is a fault on the battery's indicator. If there is a fault, please contact your battery supplier.
Auto test failure	Auto test failed	Only applied to Italy model
Lcd com failure	LCD fails to communicate with M3 microprocessor	Restart inverter. If fault still exists, contact Luxpower service or your inverter supplier.
Fwm mismatch	Firmware version mismatch between the microprocessors	
Fan stuck	Cooling fan(s) are stuck	
Trip by gfc high	Inverter detected leakage current on AC side	1. Check if there is a ground fault on the grid and load side; 2. Restart inverter. If the fault remains, contact Luxpower service or your inverter supplier.
Trip by dci high	Inverter detected high DC injection current on grid port	Restart inverter. If the fault remains, contact Luxpower service or your inverter supplier.
PV short circuit	Inverter detected short circuited PV input	1. Check if each PV string is connected correctly; 2. Restart inverter. If the fault remains, contact Luxpower service or your inverter supplier.


GFCI module fault	GFCI module is abnormal	Restart inverter. If fault still exists, contact Luxpower service or your inverter supplier.
Bat volt high	Battery voltage too high	Check if battery voltage exceeds 59.9V, battery voltage should be within inverter specification.
Bat volt low	Battery voltage too low	Check if battery voltage is under 40V, battery voltage should be within inverter specification.
Bat open	Battery is disconnected from inverter	Check battery breaker or battery fuse.
Offgrid overload	Overload on EPS port	Check if load power on inverter EPS port is within inverter specification.
Offgrid overvolt	EPS voltage is too high	Restart inverter. If fault still exists, contact Luxpower service or your inverter supplier.
Meter reversed	Meter is connected reversely	Check if meter communication cable is connected correctly on inverter and meter side.
Offgrid dcv high	High DC voltage component on EPS output when running off-grid	Restart inverter. If fault still exists, contact Luxpower service or your inverter supplier.

## 5.4 Fan replacement


Please check and clean the fans regularly. The recommended period is 6 months.

Please replace the fan by following the below diagram if there is problem with the fans. Turn off the system and wait for more than 5 minutes before disassembling the machine.


- Open the wiring cover
- Unplug the fan cable



c. Loosen the screws and remove them



d. Remove the fan fixing



e. Loosen the waterproof connector

f. Remove the fan and replace it

g. After the fan is installed, follow the steps just now to push back and assemble it back

### PV Input data

	12K
Max. usable input current(A)	25/15/15
Max. short circuit input current(A)	34/17/17
Start input voltage(V)	100
Startup voltage(V)	140
Full power MPPT voltage range(V)	230-500
DC nominal voltage(V) MPPT tracker	360
DC voltage range(V)	100-600
MPP operating voltage range(V)	120-500
Max. power(W)	18000
Number of MPPT	3
Inputs per MPPT	2/1/1

### AC Grid output data

Nominal Output Current(A)	50
Max. Output Current(A)	50
Rated voltage(V)	230
Operating voltage range(V)	180-270
Nominal power output(W)	11500
Operating frequency(Hz)	50
Operating frequency range(Hz)	50
Phase shift	0.99@full load
Reactive power adjust range	-0.8~+0.8 leading Adjustable
THDI	<3%
Sync inrush (A)	35

### UPS AC output data

Nominal output current(A)	50
Nominal output voltage(V)	230
Rated output power(VA)	11500
Operating frequency(Hz)	50
Peak power(VA)	2xPn, 0.5s
THDV	<3%
Switching Time	<20

### Efficiency

Max. Efficiency @ PV to grid	97.5%
Max. Efficiency @ battery to grid	94%
MPPT Efficiency	99.9%

### Battery data

	Lead-acid battery/Lithium battery
Type	Lead-acid battery/Lithium battery
Max. charge current(A)	250
Max. discharge current(A)	250
Nominal voltage(V)	48
Voltage range(V)	40-60

### General Data

Integrated disconnect	DC switch
Reverse polarity protection	Yes
DC switch rating for each MPPT	Yes
Output over-voltage protection varistor	Yes
Output over current protection	Yes
Ground fault monitoring	Yes
Grid monitoring	Yes
Pole sensitive leakage current Monitoring unit	Yes
Dimensions(mm)	670*490*265mm(22.8*19.3*10.4inch)
Weight(kg)	50kg(96.8 lbs)
Degree of protection	NEMA4X / IP 65
Cooling concept	FAN
Topology	Transformer-less
Relative humidity	0-100%
Altitude(m)	<2000m
Operating temperature range (□)	-25~60□, >45□ Derating
Noise emission(dB)	<50dB
Internal consumption(W)	<15W
Display	Touch color screen
Communication interface	RS485/ Wi-Fi/ CAN
Standard warranty	5years